

7072.1110 Controller Manual



There are 3 major steps to change the set value:

- 1-)Removing the Display Lock (Step 1-8)
- 2-)Changing the Set Value (Step 9-11)
- 3-)Locking the Display Screen (Step 12-19)

Removing the Display Lock

STEP-1



1-) Press and hold «SET» for 5 seconds.

STEP-2



2-) Use the Up and Down Arrow Buttons to find PA2 on the screen then press «SET» once.

STEP-3



3-) Use the Up and Down Arrow Buttons to insert the password then press «SET». Password ~ 22



STEP-4



4-) After the menu shows up («CP» is displayed first in the menu), use the Up and Down Arrow Buttons to find «d1S» parameter.

Removing the Display Lock

STEP-5



5-) Press «SET» after the «dIS» parameter is displayed.

STEP-6



6-) After the «LOC» parameter appears on the screen, press «SET» once.

STEP-7



7-) Use the Up and Down Arrow Buttons to find «n» then press «Set» once.

STEP-8



8-) Press the «Escape» button until the temperature is displayed on the screen.

Changing the Set Value

STEP-9



9-) Press «SET» once.

STEP-10



10-) Press «SET» once after the «Set» parameter is displayed on the screen.

STEP-11



11-) After the «Set» value appears on the screen, change it by using the Up and Down Arrow Buttons. When the desired value is put, press «SET». Press «Escape Button» once to see the temperature on display.

Locking the Display Screen

STEP-12



1-) Press and hold «SET» for 5 seconds.

STEP-13



2-) Use the Up and Down Arrow Buttons to find PA2 on the screen then press «SET» once.

STEP-14



3-) Use the Up and Down Arrow Buttons to insert the password then press «SET». Password ~ 22

STEP-15



4-) After the menu shows up («CP» is displayed first in the menu), use the Up and Down Arrow Buttons to find «diS» parameter.

Locking the Display Screen

STEP-16



5-) Press «SET» after the «diS» parameter is displayed.

STEP-17



6-) After the «LOC» parameter appears on the screen, press «SET» once.

STEP-18



7-) Use the Up and Down Arrow Buttons to find «y» then press «Set» once.

STEP-19



8-) Press the «Escape» button until the temperature is displayed on the screen.