

USER'S INSTRUCTIONS

Wall-mount mixing faucet for Professional Kitchens



INSTALLATION INSTRUCTIONS

- 1) Connect the eccentric fittings (a) to the wall connections
- 2) insert the cover plates (b) in the eccentric fittings
- 3) Connect the faucet (c) to the eccentric fittings fixed to the wall
- 4) Remove the screw of the faucet (d)
- 5) If you have to mount a spout (X), insert the connection of the spout (X) in the faucet's seat and tighten the fixing screw (d). If you have to assemble a Pre-Rinse Unit (Y or Z), please follow the relevant instructions.
- 7) connect the inlet pipes/flexible hoses to the water net

Operating parameters:

Maximum operating water temperature and pressure: < 90° (194°F) and < 0.65 Mpa (6.5 bar / 94.27 psi)

USE:

- Do not move swivel nozzle violently and do not hang anything on the nozzle
- Keep the faucet's surfaces clean and dry using a soft cloth, in order to prevent limestone or corrosive substances fouling (do not use aggressive and/or corrosive detergents)
- Remove the aerator often and keep it clean with suitable solvents and water
- Faucet is suitable for use with water only, do not mix water with other substances

CLEANING INSTRUCTIONS

- DO NOT clean the faucet surfaces when hot. They should be cleaned when they are at room temperature
- DO NOT use aggressive and / or corrosive detergents
- DO NOT use abrasive cleaning pads
- After cleaning with soft detergent rinse well the surfaces with cold water to remove any traces of chemicals and dry them with a soft cloth.
- Avoid contact between detergents and rubber gaskets

WARNING:

Shut down the water feed to the Pre-Rinse Unit whenever it is not used for some time, and especially during closing hours.

All packing materials are recyclable and must be disposed of according to local regulations

