

7072 Series - Manual Controller



Press and hold the «set» button on the control panel for 5 seconds



Go to PA1 parameter and press «set» key once Type the password '33' with the up arrow key and press the set key again.



After entering the parameter screen, press the up or down arrow keys. Move to the «LOC» parameter and press the «set» key.



After entering the «LOC» parameter, adjust the «eye» command and press the set button again and return to the main screen by pressing the «Stand-By» button indicated by the arrow in the picture.



Press the «set» button once from the main screen, after the set text is displayed on the screen, press the «set» button once again to switch to the set change screen.



After determining the set value you want to adjust with the up and down arrow keys, save your setting by pressing the «set» button again.

